

Weber Jet Doctor

Follow these simple, step-by-step instructions, to install your Weber Jet Doctor, and say goodbye to the problem of plugged Idle Jets



1 - Remove the Air Cleaner from the Carburetor and separate base from Air Cleaner.



2 - Remove the top off of the carburetor, and remove the gasket.



3 - Install the Jet Doctors as shown



4 - Reinstall the gasket, and then tighten the base to the carburetor.



5 - Using the supplied gasket as a template, mark the center holes



6 - Using the supplied drill bit, drill holes through the air cleaner base.



7 - Carefully re-install the A/C base, allowing the Jet Doctors through the holes.



8- Re-assemble the Air Cleaner Elements.

DON'T FORGET - Upon finishing the installation of the Weber Jet Doctor, you must readjust the Air/Fuel Mixture Ratio.

WEBER
Jet Doctor

**Installation
Guide**



CB PERFORMANCE
**HIGH PERFORMANCE
RACING PRODUCTS**

cbperformance.com

1715 N. Farmersville Blvd. Farmersville, CA 93223

Phone: (559) 733-8222 Fax: (559) 733-7967