



Ron Lummus Racing Polycarbonate Window SELECTION GUIDE

If you are not sure of year, use guide below.

If you have a 1971 Super Beetle, check the size of the back window before ordering. Late '71 Super's have the larger 1972 size rear window, so be sure to specify which one you need.

Make sure your doors correspond with the same year as the body.

(No Super Beetle Curved Windshield)

This guide is provided as a reference only. You are responsible for knowing what year, body, door style and windows you need!

The measurements below in the size chart are window openings, NOT WINDOW SIZE.

Window Opening Size (Front / Rear)	Type-1 Bug
13" / 11 1/2" (Oval)	Up to '57
14 3/8" / 15 1/2"	'58 to 64
15 1/2" / 16 1/2"	'65 to 71
15 1/2" / 18 1/2"	'72' to 77 (No Super Beetle Curved Windshield)

The pictures on the next page show how to measure the window openings.

