


These schematics are generalized instructions re-printed from VDO. Some gauges may require additional adapters, senders, or even hardware not normally sold with gauge to properly complete installation.





1715 N Farmersville Blvd., Farmersville, CA 93223 info@cbperformance.com 1-800-274-8337

cbperformance.com